Standard Accessories Model 11 List Model 10 List Model 9 List Spyder List Jib Arm List Close Window Standard Accessories Select accessory for detailed view Print This Page

Allen Wrench (AWR)

Battery Rack (PBX)

Battery Rack (BRE)

Carry Handles (CH)

Front Boards (F)

Front Boards (FE)

Front Pins (FPIN)

High Side Boards (H)

High Side Boards (HE)

High Side Boards (Left) (HTL)

High Side Boards (Right) (HTR)

Knee Bumper (BPR)

Large Seat (S)

Low Side Boards (LE)

Low Side Boards (LT)

Low Side Boards (L)

Pnuematic Wheels

Power Cord (PC)

Push Posts (for model 10 dolly) (PP10)

Push Posts (for model 11 dolly) (PP11)

Push Posts (for model 9 dolly) (PP9)

Small Seat (ST)

Standard Multi-Position Level Head (SLE)

Standard Multi-Position Level Head (SLT)

Spyder and Jib Arm Dolly Standard Accessories

(Detailed popups of these accessories are not available.)

Battery Tray

Four Way Level Head w/ Mitchell Mount

Seat Extensions

Seat Riser

Steering Post

Swivel Seats

Close Window Print This Page

J.L. Fisher, Inc. / 1000 Isabel Street / Burbank CA 91506 USA Tel: 818.846.8366 / Fax: 818.846.8699 / www.jlfisher.com

1 of 1 6/28/06 7:26 PM